

90/0 Collon/Viscose 00/40 Collon/polye

Due to the nature of printed fabrics, special care must be taken throughout the printing process. Due to the special nature of these vibrant colours (Extreme Pink & Extreme Yellow), please wash according to the wash instructions before wearing to avoid colour transfer.

ATC8001L - ATC[™] EUROSPUN[®] Ring Spun V-Neck Ladies' Tee

GARMENT MEASUREMENTS											
Size	XS	S	м	L	XL	2XL	3XL	4XL			
Chest - Half Measure	15 1/2"	16 1/2"	17 1/2"	19"	20 1/2"	22"	24"	26"			
Chest - Full Measure	31"	33"	35"	38"	41"	44"	48"	52"			
Body Length from HPS	25 3/4"	26 1/4"	26 3/4"	27 3/4"	28 3/4"	29 3/4"	30 1/4"	30 3/4"			
Sleeve Length-CB	13 3/4"	14"	14 1/4"	14 3/4"	15 1/4"	15 3/4"	16"	16 1/4"			

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

LADIES' General Sizing Guide											
Size	XS	s	м	L	XL	2XL	3XL	4XL			
Numeric Size	2	4-6	8-10	12-14	16	18-20	22	24			
Bust	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"			
Waist	24"-25"	26"-27"	28"-30"	30"-32"	33"-35"	36"-38"	40"-42"	42"-44"			
Нір	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"			
Sleeve Length-CB	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"			



DECORATION RECOMMENDATIONS FOR PRINTED FABRICS:

Due to the nature of printed fabrics, special care must be taken throughout the decoration process. Here are some tips to effectively decorate printed fabrics:

Screen Printing Tips:

- Garment dyes may bleed through screen printed inks, especially when printing on top of print that contains red dye. Sublimation will be most noticeable when using white or light colour inks and may take 24-48 hours to occur.
- Use base blocker ink first (grey works best)
- Using low bleed poly ink is recommended
- Use coarse mesh
- Do not exceed recommended dryer temperature
- Check with your ink supplier for other tips

Heat Transfer Tips:

- Use of vinyl heat transfer may help minimize sublimation
- · Use cover sheet/flexible application sheet to shield upper platen from sublimation dyes
- Do not exceed recommended temperature
- · Check with your heat transfer supplier for other tips

A test sample run is recommended, especially if you have a large order or if your decorator does not specialize in printed fabrics.